

Engineering Control Development

Known:

1. Dose for complete 10-hour shift is 325%
2. Operator ear sound levels:
 - 95 dB(A) while tramming – 2 Hrs
 - 100 dB(A) while drilling – 5 Hrs
 - 90 dB(A) during maintenance/down time – 2 Hrs
 - 80 dB(A) while on break – 1 Hr

Engineering Control Development

Calculation of % Dose (PEL)

$L_{p'}$ dB(A)	Time Allowed (hrs)	%Dose per hour
<90	∞	0
90	8.0	12.5
91	7.0	14.4
92	6.1	16.5
93	5.3	18.9
94	4.6	21.8

$L_{p'}$ dB(A)	Time Allowed (hrs)	%Dose per hour
95	4.0	25.0
96	3.5	28.7
97	3.0	33.0
98	2.6	37.9
99	2.3	43.5
100	2.0	50.0

Engineering Control Development

Exposure Contributions:

Drilling – 250%

Tramming – 50%

Maintenance/Downtime – 25%

Drilling Solutions:

A well designed windshield ~ -3 dB(A)

– 97 dB(A) for 5 Hrs \Rightarrow Drilling – 165%

A well designed cab ~ -20 dB(A)

– 80 dB(A) for 5 Hrs \Rightarrow Drilling – 0%

Engineering Control Development

Tramming Solutions:

A well chosen muffler \sim -15 dB(A)

- 80 dB(A) for 2 Hrs \Rightarrow Tramming - 0%

Maintenance/Downtime Solutions:

A well designed fan silencer \sim -20 dB(A)

- 70 dB(A) for 2 Hrs \Rightarrow Maintenance - 0%

Engineering Control Development

Before:

1. Dose for complete 10-hour shift is 325%

After:

1. Dose for complete 10-hour shift is:
 - 165% with a windshield and all other controls
 - 0% with a cab and all other controls

Engineering Control Development

Before	After
Tramming 95 dB(A)	Tramming 80 dB(A)
Drilling 100 dB(A)	Drilling 97 or 80 dB(A)
Maintenance 90 dB(A)	Maintenance 70 dB(A)